

Addressable manual alarm call point



Addressable resettable call point, for manual fire alarm signaling. Manual operation, Type A (direct).
Module operating statuses can be used as operands in formulas.
RSC® management: programming, remote management and control. Loop connection. Dual short-circuit isolator.
Installation mode: with piping in visible execution with tube box.
Supplied accessories: tube box, opening key and reset button. Outdoor use. Protection rating IP55. Polycarbonate casing V0.
Red colour. Dimensions with tube box (L x W x D) 93 x 88 x 76mm.
Approved EN 54-11:2001+A1:2005 - EN 54-17:2005. Certification 1293-CPR-0807.

MODEL										
Name	Item no.									
TFCP-IP55	TF5TFCPIP55									

OBLIGATIONS AND NOTICES

The TFCP button can only be used when connected to a compatible Tecnofire control unit detection loop. In the planning and installation phases, the regulations in force must be observed and applied.

ADDRESSING

The physical address which identifies the button is set using two decimal rotary switches located inside the enclosure, under the actuation surface.
The two switches enable to set the two digits which make up the physical address number of the device.
The switches are marked by writings which define the position of the digit to set: X10 for tens and X1 for units.
The numeric range of the allowed addresses for the button modules is 01 to 99.
Note: setting the address 00 excludes the button from operation, yet it draws power from the loop.

	Alarm call point 1 logic unit Physical address = XX	← X Units ← X Tens
--	---	---------------------------

SHORT-CIRCUIT ISOLATOR

The button is equipped with a line separator with double insulator. In the event of a short circuit of the Loop line, the separator intervenes by isolating the section of line affected by the fault, thus safeguarding the correct functioning of the devices connected upstream and downstream.
The intervention of the line separator preserves the smooth operation of the loop and generates the failure signal "Separator open".



TFCP-IP55

Addressable manual alarm call point


ADDRESSABLE

EQUIPMENT AND ACCESSORIES

The call point is supplied with a base and a pipe box.
To protect the button from vandalism and accidental impacts, the optional transparent TFCP-COP anti-vandal cover is available. A clamp can be attached to the protective door to seal its opening.


INSTALLATION

Installations with surface-mounting pipes, fix the pipe box to the wall and mount the base with the terminal board and pushbutton on it.




OPENING THE CASING

To open the button, it is necessary to use the opening and reset key supplied. Position the key at the interlocking seats, push upwards until the button releases, then turn and lift the button upwards until it separates from the base.



RESETTING THE CALL POINT

To reset the call point, inserted the reset key must be into the reset slide and pushed all the way in. During installation, it is possible to choose the reset mode of the pushbutton, if the key insertion locking tab has been cut, the user can reset the call point, if, on the other hand, the locking tab has not been cut, insertion of the reset key is blocked, in this case the reset can only be carried out by qualified technical personnel authorised to open the call point to carry out the reset.



DIAGNOSTIC FUNCTIONS

Tecnofire control units manage a series of specialised diagnostic functions for each type of device. The diagnostic functions available for the addressed button allow you to:

- Physically identify the module.
- Identify the device type.
- Identify the HW and FW version.
- Detect electrical operating data.
- Read statistics from the communication monitor.

31/01/2024	Access level 3	08:00:00
Menu Test module 3 Loop 1		
Identification	TECNO - call point	
Self declaration	0.1	
HW release	3.1	
FW release		
Level reading		
Statistic		



DIAGNOSTIC FUNCTIONS OF THE MODULE TECNO-call point	
Identification	Turns on the Led of the device for its identification
Self declaration	Self declaration of the module type
HW release	Self declaration of the hardware version
FW release	Self declaration of the firmware version
Level reading	Measurement of the electric values of operation
Statistic	Statistic/functional values related to communication

Consumption	Strings sent
Power supply level	Errors
Zero level	Percentage of success
Consumption level	Percentage of errors
Loop resistance	Latency

31/01/2024	Access level 3	08:00:00
Level analysis Loop 3 Module 1		
Consumption	51 mA	
Power supply level	26.44 V	
Zero level	0.51 V	
Consumption level	5.49 V	
Loop resistance	<1.00 Ohm	
active		

CONNECTION TO THE LOOP


The modular structure of the push button facilitates wiring operations; the connection terminal block, fixed on the base, engages with a guided joint on the push button body.




TERMINALS				
1	LOOP-	Negative power Loop output		
2	LOOP+	Positive power Loop output		
3	LOOP-	Negative power Loop input		
4	LOOP+	Positive power Loop input		
5	LOOP+	Positive power Loop input (no isolator)		

DEGREE OF PROTECTION IP55

To maintain the characteristics required by the IP55 degree of protection, it is mandatory to install the call point with the gaskets and the tube box supplied; the tubes must be connected to the box in visible execution.



TYPICAL INSTALLATION



TFCP-IP55

Addressable manual alarm call point

Accessories

	TFCP-COP
	Transparent anti-vandal cover with anti-opening clamp, for TFCP-C and TFCP IP55 series call points. Pack: 10 pieces.
	Item no. TF5TFCOPCP

	TFCP-KEY
	Opening and reset key for TFCP-C and TFCP IP55 series call points. Pack: 10 pieces.
	Item no. TF5TFKEYCP

	TFCP-PLEXI
	Plexiglass location sign, with push-button lock, reversible position. Conforms to UNI EN ISO 7010. Dimensions (L x H) 153 x 153mm.
	Item no. TF5TFCPPX



With TFCP-PLEXI sign

Technical and functional specifications

General information	Addressable manual alarm call point	TFCP-IP55
	Function	Fire alarm activation
	Actuation	Type A direct
	Area of use	For outdoors
Loop interface	Addressable module	Connection over loop
	Addressing	2 rotary switch
	Communication protocol	FIRE-SPEED
	Loop isolator	Double insulator
	Polling frequency	Programmable
	Polling signaling Led	Excludable
Electrical specifications	Nominal voltage	24V DC
	Operating voltage	18V...30V DC
	Consumption	500µA @ 24V DC
	Consumption in alarm	1,6mA @ 24V DC

Programmable functions	Functioning criterions	5 modes
	Evacuation signalling	Associable
Physical specifications	Operating temperature	-15°C...+70°C
	Relative humidity (non-condensing)	10%...93%
	Protection class	IP55 (EN 60529)
	Casing	PC
	Dimension with tube box (L x H x D)	93 x 88 x 76mm
	Color	Red
	Weight	300g
Conformity	Standards	EN 54-11:2001+A1:2005 EN 54-17:2005
	System compatibility	UNI EN 54-13:2020
	Certification number	1293-CPR-0807
	Year of CE marking	21
	Number of declaration of performance	026_TFCP-IP55
	Notified body	EVPU

N.B. Declarations of conformity and performance are available on www.tecnofiredetection.com



EVPU
Tested



Tecnofire
DETECTION
by Tecnocalarm S.r.l. - Via Ciriè 38 - 10099 - San Mauro T.se - Torino (Italy)
Manufacturing plant: Strada del Cascinotto 139/54 - 10156 - Torino (Italy) - www.tecnofiredetection.com

The product features can be subject to change without notice.

MADE IN ITALY

TFCP-IP55 - DATA SHEET - REL. 2.0